



SWDL6

12V Halogen - 20cm (8")

Driving Lights

Information for use _____

IMPORTANT - Please Read: Only install these lights if you have prior knowledge or experience of installing electrical equipment to your vehicle. Otherwise, please seek assistance from a qualified, competent professional.

Intention For Use

Thank you for purchasing this pair of 12V Halogen 8" Driving Lights from Streetwize. These lights are primarily designed for driving off-road, and they provide added brightness when driving at night or in low light conditions.

These lights are NOT intended for use on motorcycles and for on-road driving. It also should NOT be used with a 230V mains power supply, this includes home lighting and commercial lighting.

Before installing & using these lights, we advise that you read through all the information in this document. Please keep this document for future reference.

Product Elements

Pair of halogen driving lights with mounting brackets pre-fitted.

Installation Instructions

IMPORTANT: These halogen driving lights must be fitted at the base of the front of your vehicle. When positioning these lights on your vehicle, it should not interfere with head lights or indicator lights.

PLEASE READ: Please refer to your vehicle's handbook on the electrical wiring in your vehicle. The instructions below are generic and should be used as a guidance

What you need for this installation

- Drill
- 8mm drill bit
- Marker pen
- Red wiring (length will vary depending on the vehicle)
- Black wiring (length will vary depending on the vehicle)

1. First ensure your vehicle is fully switched off.
2. Find a suitable position to mount these driving lights. Make sure that you find an appropriate position on the front of your vehicle, where the driving lights will not block the headlights or the indicator lights.
3. Mark where you are going to drill the holes with a suitable marker pen (not included). Since you are installing two lights, you will only need to drill two holes. Make sure there is an even gap between the holes.
4. Then with a 8mm drill bit (not included), drill the holes where you have made your marks (drill not included).
5. Using the fitted mounting bracket, secure the lights via the newly drilled holes. Ensure the lights are securely in place.
6. With the red wire, connect to the light's white cable (figure 1). Thread the other end of the red wire to the positive terminal of your vehicle 12V battery.
7. With the black wire, connect it to the light's black cable (figure 1). Thread the other end of the black cable and then connect it to a metal part of your vehicle so that it is earthed.
8. Check all the cables are connected properly before testing.

Fig 1



Health & Safety Guidelines

1. Only people with knowledge and experience should attempt to install these lights to your vehicle.
2. This product is not a toy. Please keep children supervised at all times when they are using this product.
3. Always ensure your vehicle is fully switched off when installing this product.
4. Always ensure the black cable is earth.

Health & Safety Guidelines

If you require any technical support, please contact us on support@streetwizeaccessories.com and provide the product name and supplier code (see Technical Specifications) along with the technical query.

Technical Specifications

Name	Streetwize 12V Halogen Driving Lights - 20cm (8")
Supplier Code	SWDL6
Voltage	12V
Bulb	H3-55W
Size	20cm (8")



Streetwize, Ashburton Road West,
Trafford Park, Manchester, M17 1RY

For Product Support:

E: support@streetwizeaccessories.com

T: +44 (0)161 447 8597

For Trade Enquiries:

E: sales@streetwizeaccessories.com

T: +44 (0)161 447 8580

EU Regd. Address: Ace Supply Co (Europe) Ltd. D02 A098, ROI

www.streetwizeaccessories.com