



Pair of Rock Steady Towing Mirrors



Read and understand these instructions before fitting these mirrors and retain for future reference!

Fitting Instructions.

Please check there are 2 Rock Steady Mirrors (1x Flat & 1x Convex) in handy storage bags with all straps, fittings and lanyards (attached to the mirrors arm) are included for each mirror.



1

To keep the mirror from being lost when in use, a handy lanyard has been included on the mirror arm. Place the lanyard over the mirror and pull to secure.



2

Ensure the securing straps are threaded correctly as shown opposite. If required additional protection pads are included for securing the mirror.



3

Place the clips on the mirror arms over the back of the mirror securing the clips under the top rim of the vehicle mirror and secure in place with the pinch screws.

**4**

The mirror arm can then be adjusted along its length, when the arm is in the desired position, secure in place with the pinch screws as shown opposite.

**5**

Pass the rubber securing straps around the back of the mirror and secure the clip on the bottom rim of the mirror, use the stretch of the rubber strap to get tight fit to keep the mirrors secure.





6

It is recommended that the convex mirror (magnified) is placed on the passenger side and the flat mirror on the drivers side. If necessary the mirrors can be swapped for left hand drive cars, by removing the screw on the arm near the ball joint and swapping the mirrors around. The ball joint on the rear of the mirror allows you to easily position the mirror at any angle.

**Streetwize Accessories:**

Unit 1, Royce Trading Estate, Ashburton Road West,
Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com

www.streetwizeaccessories.com