



SWWL10

# Folding - 3 Leg Parking Barrier

**Fitting instructions:** Choose a suitable location for the Parking Barrier ensuring there will be enough space to lay the barrier flat when not in use. Match the parts with their letters below and assemble in order, and ensure ALL bolts are fitted correctly for maximum security\*.

A		1x	B		1x
C		1x	D		2x
E		1x	F		2x
G		2x	H		1x
I		3x	J		9x
1			2		
3			4		

Fit foot plates (D) using the bolts (J) to fix securely to the ground using a suitable drill and bit, and tighten the bolts to secure.

Fix the bolts for the 3rd leg and secure as (D). To lock the barrier in position, place the Brass pad lock through the holes on B & C and lock in position.

\* No responsibility will be accepted by Streetwize for use of this product in the case of theft. Please take care of the pad lock key as spares are not available for security reasons.

**Streetwize Accessories:**

**Technical enquiries:** [support@streetwizeaccessories.com](mailto:support@streetwizeaccessories.com) [www.streetwizeaccessories.com](http://www.streetwizeaccessories.com)