

Induction Kit

MPUAF1-8-9

Replacement Sports Filter



INSTALLATION INSTRUCTIONS

The universal sports induction kit contains the following parts:

- High flow cone air filter
- Set of adaptor rings

PLEASE FOLLOW THE PROCEDURE BELOW CAREFULLY. IF IN DOUBT, SEEK ASSISTANCE OR ADVICE.

1. Remove the original air filter box and check that the new filter will fit in the space available. In some cases, it may be necessary to make a support for the air flow meter.
2. Measure the diameter of the induction hose or pipe and select the appropriate adaptor ring to be fitted in the next of the new filter.
3. Having fitted the correct adaptor ring, fit the new filter to the induction hose, utilising the hose clip provided. It is essential that no air leaks occur at this joint, as this can lead to lean mixture, resulting in poor engine running or even engine damage. Ensure the filter is installed tightly and correctly. There should be sufficient clearance between the filter and any high temperature source as an incorrectly installed filter may cause life threatening situations. Never use self-locking nuts that have been used before, always use new ones.
4. It may be necessary to adjust the CO or tuning of your engine depending on your particular fuel system.
5. We recommend cleaning the filter with a suitable cleaning agent every 2500km. Filters should be properly cleaning and dried before re-installation.

Streetwize Accessories:

Unit 1, Royce Trading Estate, Ashburton Road West,
Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com

www.streetwizeaccessories.com