

Griffon Door Canopy

Please read this manual carefully before first use to ensure safe installation, correct operation, and long-lasting performance.

BEFORE USE PLEASE BE AWARE - A new canopy may initially leak slightly at the joints. It is **ESSENTIAL** when purchased to give the canopy a good soaking with a hose, this will allow the stitching to swell. It may take several attempts to fully seal all of the joints, but after it has weathered, it should be completely waterproof. **ALWAYS ensure that the canopy is fully dry again before dismantling.**



Before Use

When you first receive your canopy check the following is included to avoid inconvenience when fitting.

Griffon Canopy	1
Pegs	4
Storm Straps	4
Carry-bag	1
Hand Pump	1

Assembly instructions:

DO NOT USE a knife to open the carton, the canopy is packed tightly into the box, and it is very easy to cut through the cardboard and the item inside.

- 1 Ensure the ground is free of stones and other sharp objects. Unpack and familiarise yourself laying the canopy out flat on the ground.
- 2 Thread the Griffon canopy bead into the caravan awning channel and slide into place.
Take care to position the Griffon correctly ensuring that the canopy is seated in the required position.

- 3 Inflate the main and the centre beam (Do not over inflate your Griffon support beams). We recommend that you inflate the canopy: Spring time up to 23 degrees 7Psi, Summer 23 degrees + 5Psi.
- 4 Using the anchor straps secure the canopy to the bottom of your caravan.
- 5 Once you are happy, proceed to peg the storm straps and tighten accordingly.

Dismantling

To dismantle the canopy, simply reverse the erection procedure. All beams must be deflated, open all valves to aid the dispelling of the air, then the canopy should be carefully rolled and dry prior to placing back in the carry-bag. When putting your canopy away ensure that the canopy is dry and free from excessive moisture/dirt.

Weathering

New canopies can often leak from the sewing machine holes in the fabric, these will swell up and seal once the canopy has become wet, this is known as weathering the process. Weathering allows water droplets to penetrate the webbing to begin with, but the cotton fibres in the thread will eventually swell and nestle into each other, closing the holes. The result is a water-resistant canopy and one that will give years and years of good service if it is looked after properly. For the weathering process to be completed it is important that the canopy dries thoroughly between initial set-up and after any use.

Maintenance & Care

- Ensure the canopy is fully dry before packing to prevent mildew.
- Store in supplied carry bag in a cool, dry place.
- Do not use in strong winds, storms, or extreme weather.
- Inspect regularly for wear: straps, clips, seams, and fabric panels.
- Avoid hanging heavy items from the structure.
- Ensure the canopy does not obstruct the caravan door opening.
- Avoid pitching under low branches or near sharp objects.

Product Specifications

Product Name:	Griffon Door Canopy
Supplier Code:	LWA68
Size:	W180 x D50 x H235-290cm
Material:	150D Oxford PU3000mm, TPU Air Tube frame
Fabric Weight:	100gsm
UV Protection:	UPF50+

**Leisurewize, a brand of the Ace
Supply Company Ltd. (Streetwize)**
Suite GA, Marsland House
Marsland Road, Sale M33 3AQ

For Product Support:
support@leisurewize.com

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI

WWW.LEISUREWIZE.COM