


Dual Camera HD Dash Cam



Please note: The internal battery for this Dash Cam is for playback and storing the system settings only. The Camera must be powered by the 12V power cable supplied or hard wired to the vehicle power supply to record any journeys.

Please read and understand these instructions carefully before operating this Dual Camera HD Dash Cam and retain for future reference. Refer to manual instruction to operate the camera correctly. Illegal operation may cause damage to internal components. Dropping the camera may damage the internal components. Do not alter or dismantle the camera. The temperature of the camera may rise when in use for a long time. Do not touch the lens when recording which will affect the video quality.

CAMERA INTERFACE



- 1. Power button
- 2. UP button
- 3. Menu button
- 4. Down button
- 5. OK button

- 6. Mode button
- 7. Lock button
- 8. Micro SD Card slot
- 9. USB port
- 10. Front lens

- 11. Back lens
- 12. Microphone
- 13. Speaker
- 14. Reset

BUTTON FUNCTION

Power button:

Short press to turn on camera;
Long press to turn off camera;
In Standby mode, short press to turn on/off the night vision LED.

UP button:

In Menu Setting, short press to choose the options. In Playback Mode, short press to choose the files. During playback, short press to decrease volume.

OK button:

In Standby mode, short press to start/stop recording. In Picture mode, short press to take photo.

Down button:

In Menu Setting, short press to choose the options. In Playback mode, short press to choose the files. During Playback, short press to increase volume.

Menu button:

In Standby mode, short press to enter menu setting.

Mode button:

In Standby mode, short press to switch between Video mode, Picture mode and Playback mode.

Lock button:

During video recording, short press to lock the video.

CAMERA OPERATION

Power on/off

Power on: Short press power button, screen shows start up picture, the blue working indicators will light up, camera enters standby mode.

Power off: When camera is on, long press power button to switch the camera off.

Battery Charging

Connect camera with car charger via USB cable, the red light will light up. Once the battery is full, the red light will be off. Turn off the camera when charging to charge battery faster.

Video Mode

Normal recording: Closing "seamless" in the video mode menu, Press OK button, camera starts recording till card is full. Press OK button again to stop recording.

Seamless recording: (refer to menu setting) In standby mode, press OK button to start recording, the blue indicator will flash. When the video recorded up to the time you set (1 minute/2 minute/3 minutes/5 minutes), camera will save the footage automatically and continue recording. When TF card is full, camera will overwrite the first footage by time sequence and continue recording.

Picture Mode

Camera default setting is Video mode, short press Mode button to enter Picture mode. Aim at the object you want to shoot and press OK button, camera will save pictures automatically.

Playback Mode

In Video mode or Picture mode, short press Mode button to enter Playback mode, press Up or Down button to select the files. Short press OK button to start playback, press OK button again to pause the playback. Press Mode button again to back to video mode.

TECHNICAL SPECIFICATION

Video Resolution	Front: 1080P 30fps, 720P 30fps Rear: VGA 30fps
Sensor	Front: 1.3M Cmos Rear: 0.3M Cmos
Lens	120 degree
Rear Lens	330 degree swivel camera
Image Size	12M
Screen	2.7" Colour LCD Screen
Audio	Built-in Microphone/Speaker
Storage	Micro SD Card, supports up to 32G
File Format	JPEG/AVI
Battery	Built-in Rechargeable Li-ion battery (280mAh)
Working Time	10 minutes
Loop recording	Support
Night Vision	Support
Port	USB 2.0 / AV Out
G-sensor	Support
Motion detection	Support
Accessories	Suction cup, car charger, USB cable

WARRANTY: To validate the warranty on this product, please go to our website and enter your details on the warranty screen. www.streetwizeaccessories.com

Streetwize Accessories:

Unit 1, Royce Trading Estate, Ashburton Road West,
Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com

www.streetwizeaccessories.com



M17 1RY