



SWGSL248

Set of 2 Solar Powered LED Crackle Balls

READ THE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND INSTALLATION.

BEFORE FIRST USE: Remove the protective film from the solar panel.

CHARGING AND OPERATION:

1. There is an "on/off" switch at the back of solar panel case, Push the switch to "on" position. Then replace the cover and position the light in a sunny location. Charge the solar product by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.
NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

IMPORTANT:

1. Install the solar product in an area where it can get direct sunlight.
2. Leave the switch to "ON" position.
3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.

MAINTENANCE AND TROUBLESHOOTING:

1. Make sure the switch is set to "ON" position.
2. Keep the solar panel clean.
3. If solar product does not light up after it has been used for around 8 - 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1 pc "AA" 1.2v 400 or 600Mah, Ni-MH, Rechargeable - Same equivalent type as recommended must be used).
4. Battery replacement: **Step 1:** Unscrew the battery compartment cover by using a Phillips head screwdriver (not included). **Step 2:** Remove the exhausted battery and install a new AA rechargeable battery according to the +/- polarity indicated on the product. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged. **Step 3:** Replace battery compartment cover, screw it back into position and make sure it is properly sealed.

BATTERY WARNING:

Battery must be recycled or disposed properly.

Do not dispose battery in fire or in to a Bin directly. Battery may explode or leak. Remove battery from product if storing product for long period of time. Removal and replacement of battery should be carried out by an adult.

IP44 CE



Streetwize Accessories:

Unit 1, Royce Trading Estate, Ashburton Road West,
Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com

Telephone: 0161 447 8597

www.streetwizeaccessories.com