LW752

Double Action Pump with Built-In Pressure Gauge

Intended Use

This manual air pump is designed for inflating compatible low-pressure inflatable products using the appropriate valve adaptor.



Before Use

- Inspect the pump, hose, pressure gauge and adaptors for damage.
- Check the recommended inflation pressure shown on the inflatable product.
- Select an adaptor that fits the valve securely.
- Place the pump upright on a firm, level and stable surface.
- Connect the hose securely to the pump outlet marked INFLATE.
- Attach the correct adaptor to the end of the hose, if required.
- Do not use the pump if any part is damaged, loose or blocked.

Inflation

- Insert the hose or adaptor securely into the inflatable product's valve.
- Place both feet firmly on the pump's footplates.
- Hold the handle securely with both hands.
- Raise and lower the handle using steady, controlled movements.
- Monitor the pressure gauge regularly while inflating.
- Stop inflating when the pressure recommended by the inflatable product manufacturer is reached.

Maintenance

- Unscrew the cap & pull it out together with the piston, clean the inner cylinder & the piston & take care that the sealing rings are always lubricated. Replace the piston carefully into the cylinder.

Leisurewize, a brand of the Ace Supply Company Ltd. (Streetwize)
Suite GA, Marsland House
Marsland Road, Sale M33 3AQ

For Product Support:
support@leisurewize.com

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI