

SWAC11



This 12V air compressor has been engineered to inflate most vehicles including car, van, 4x4 and light commercial vehicle tyres to their maximum pressure requirement. It is not designed for HGV's or commercial truck tyres.

IMPORTANT SAFETY INSTRUCTIONS Please read the entire instruction manual before use and retain for future reference. Your battery may not be at full strength. It is essential that you keep your engine running when operating the compressor. This will also shorten inflation time and protect your battery. Do not do this in a closed garage due to fumes circulation in a confined space.

SAFETY WARNING: NEVER LEAVE THE COMPRESSOR UNATTENDED WHILST IT IS IN OPERATION.

FUNCTION

- The 12V air compressor is built into a robust plastic carrying case with storage compartments for the air hose and 12V power lead and accessories.
- 2. Pressure gauge is accurate up to 300psi.
- 3. Includes a built-in light which can be used as a warning light with the red flip lens closed or as a work light with the flip lens open.
- 4. It has a cooling fan included which runs when the compressor is working.

OPERATING INSTRUCTIONS - TO INFLATE TYRES

- 1. Insert the 12V plug into your vehicle 12V power socket.
- 2. Place connector on the valve stem and push down as far as possible.
- 3. Switch the air compressor on.
- 4. When the correct air pressure is reached, switch the air compressor off.
- 5. Remove the adaptor form the tyre valve and remove the 12V power cord from the socket.
- 6. Always leave the thumb lock in the open position when storing the compressor.

NOTE: The tyre will not expand at the same rate during the final phase of inflation as it does at the beginning of the process. This is due to the fact air flow in the tyre from compressor decreases as the required tyre pressure is reached. Check with tyre pressure gauge for proper inflation.

SWAC11 Manual AW 2019.indd 1 08/04/2019 15:50

INFLATION TIME

Inflation time will vary depending on the article inflated and the pressure required.

FOR INFLATABLES

- 1. Select the suitable adaptor and insert it into the connector Close thumb lock.
- 2. Check your owners manual for exact pressures required. Insert adaptor into article to be inflated.
- 3. Plug power cord into 12V power socket and switch on the compressor. When pressure is reached, switch off the compressor and remove 12V plug from socket.
- 4. Remove adaptor from inflated item, remove adaptor from connector. Remember to leave thumb lock in open position when storing.
- 5. Always inflate items with correct pressure. Avoid excess pressure in low pressure objects.

WARNING

Do not exceed recommended pressure of items being inflated. Be careful with bicycle tyres and other small items as they inflate quickly. Beach toys and air mattresses require low pressure inflate until firm.

TROUBLE SHOOTING

IF COMPRESSOR FAILS TO START:

- 1. Check 12V power socket it working.
- 2. Socket must be clean. Remove foreign matter.
- 3. 12V power socket fuse may need replacing.
- 4. If there is a circuit breaker behind power socket, replace if blown.

COMPRESSOR RUNS BUT DOES NOT INFLATE:

- 1. Ensure connector on the valve has been pushed down as far as possible before closing thumb lock.
- 2. Check item for leaks.
- 3. Check hose for breaks and leaks at fittings.

IF COMPRESSOR RUNS SLOWLY:

- 1. Overheated from excessive use. Unplug power coed and leave it to cool for 30 minutes.
- 2. Voltage too low check condition of battery.

CAUTION

- 1. Do not run the compressor for more than 10 minutes at a time. If you need to use it for longer, turn it off and let it rest for 10 minutes before starting again.
- 2. When running at more than 75psi, do not operate for more than 7 minutes.
- 3. When using the compressor, never leave it unattended.
- 4. The compressor is capable of inflating to 300psi. To avoid over inflation, follow operating instructions as required. Do not exceed recommended pressure at any time.
- 5. The compressor should be kept out of reach of children.
- 6. Ensure the connector is screwed until the valve system until it locks firmly in place.

Streetwize Accessories:

Unit 1, Royce Trading Estate, Ashburton Road West, Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com
Technical enquiries: support@streetwizeaccessories.com
+44 (0)161 447 8597 www.streetwizeaccessories.com



WARRANTY: To validate the warranty on this product. Please visit our website and click on the warranty button and enter your details www.streetwizeaccessories.com

SWAC11 Manual AW 2019.indd 2 08/04/2019 15:50