



LW700

# Caravan Front Towing Protector

Information for use



PRODUCT INFO [streetwise.online/LW700](https://streetwise.online/LW700)

*Produktinformation*  
*Information du produit*  
*Información sobre el producto*

---

## Intention For Use

Thank you for purchasing this Front Towing Caravan Cover from Leisurewize. This caravan cover is intended to be used to protect the front part of your caravan from dirt, grime and dust during transit. This caravan cover is suitable to fit most caravan models, including both single axle and double axle caravans.

The cover is highly durable and is made from a heavy duty non-woven material.

Before attaching this caravan cover to your caravan, we highly recommend that you read through all the information in this document.

---

## Product Elements

1. Leisurewize Front Towing Caravan Cover
  2. 2x LED lights (batteries not included)
  3. Storage bag
- 

## Installation Instructions

**TIP:** We recommend getting two people involved when attaching the caravan cover to your caravan.

**IMPORTANT:** Depending on the make and model of your caravan, you may need to purchase an additional awning rail if your caravan does not come with railings on either side.

1. Prior to attaching the caravan cover to your caravan, clean the front side of your caravan using a suitable caravan cleaner. Also, do NOT hitch your caravan to your vehicle.
2. Remove the caravan cover out of its supplied storage bag.
3. Carefully unfold the caravan cover, making sure that it does not touch the ground to avoid the cover picking up any unwanted debris or elements.
4. Then, unbuckle straps on either side of the caravan cover. There should be 7 on each side (14 altogether).
5. On the front of the caravan, locate the railing on either side where you can thread the buckle straps that you've removed from the cover. Then, thread 7 buckle straps on both sides. Ensure there is a gap of around 15 to 20cm between each buckle strap.

6. Once the buckle straps are on the caravan's railings, get the caravan cover and secure the cover's bottom loop strap around the front tow.
7. Then proceed to attach to the caravan via the buckle straps that you have threaded onto either side of the caravan.
8. Once all the buckles have been fastened, adjust the buckle straps to securely tighten the cover onto the caravan. You may need to adjust the buckle's positioning on the railing for a secure fit.

*When you have successfully attached the cover to your caravan, you can hitch your caravan to your vehicle.*



---

## After Use

To remove the cover, simply unbuckle all of the straps and carefully remove the cover from the front and place the cover inside the supplied storage bag.

You can leave the buckles on the railing. However, if you are going to park up your caravan during off-season, then remove the buckles from the railing to prevent them from being worn out.

---

## LED Lights

This product comes supplied with two battery powered LED lights. These LED lights do NOT come with batteries. They each require 3 x AAA batteries to operate.

To insert the batteries in to the LED lights, remove the reverse panel by rotating the panel anti-clockwise until it stops, then pull open. Replace the panel once you have inserted the batteries.

To turn on the LED light, simply press the button where the LED light is. Press again to turn off.

---

## Maintenance

This product comes supplied with two battery powered LED lights. These LED lights do NOT come with batteries. They each require 3 x AAA batteries to operate.

To insert the batteries in to the LED lights, remove the reverse panel by rotating the panel anti-clockwise until it stops, then pull open. Replace the panel once you have inserted the batteries.

To turn on the LED light, simply press the button where the LED light is. Press again to turn off.

---

## Technical Specifications

<b>Supplier Code</b>	LW700
<b>Product Name</b>	Leisurewize Front Towing Caravan Cover
<b>Dimensions</b>	180cm x 220cm
<b>Weight</b>	1.35kg
<b>LED battery requirement</b>	3 x AAA (6 x AAA for both)
<b>Cover fabric</b>	160gsm Non-Woven

---

## Technical Support

If you require any technical support for your product within the warranty period, please contact us on:

**[support@streetwizeaccessories.com](mailto:support@streetwizeaccessories.com)**

and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.



---

**Leisurewize**, Ashburton Road West,  
Trafford Park, Manchester, M17 1RY

**EU Regd. Address:** Ace Supply Co (Europe) Ltd. D02 A098, ROI

[www.streetwizeaccessories.com](http://www.streetwizeaccessories.com)

---

---

### For Product Support:

**E:** [support@streetwizeaccessories.com](mailto:support@streetwizeaccessories.com)

**T:** +44 (0)161 447 8597

### For Trade Enquiries:

**E:** [sales@streetwizeaccessories.com](mailto:sales@streetwizeaccessories.com)

**T:** +44 (0)161 447 8580

---