LW768

leisurewize

Orli Table Lamp



Thank you for purchasing the Orli Table Lamp. This Scandinavian-style lamp combines natural wood elegance with warm ambient lighting, making it perfect for bedrooms, living rooms, or portable use. Please read this manual carefully before use to ensure safe and correct operation.

Health and Safety Guidelines

- Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
- The appliance is intended for household use only. Commercial use invalidates the warranty, and the supplier cannot be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
- Check the charging cord regularly for any damage. The cord will need to be replaced if it is damaged.
- Do not use the appliance if it has been dropped or damaged in any way. If the unit is damaged, take it in for examination and/or repair by an authorized service agent.
- To reduce the risk of electric shock, do not immerse or expose the assembly, plug, or cord to water or any other liquid.
- Do not pull on the cord to disconnect the appliance.
- Ensure that the cord is not in a position where it can be pulled inadvertently.
- Do not allow the cord to touch hot surfaces, and do not place it on or near a hot gas or electric burner or a heated oven. Do not place the unit on a hot surface.
- Do NOT carry the unit by the power cord.
- The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use or for repairs carried out by unauthorised personnel.
- In the event of technical problems, switch off the appliance and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment, or repair.
- We do not recommend using extension cords with this product.
- Keep away from curtains, bedding, and other flammable materials.
- Do not use the lamp while charging near water or damp areas.
- Avoid applying excessive pressure or force to any part of the lamp.
- Use only the supplied or manufacturer-approved USB charging cable.
- Disconnect the USB cable before cleaning or maintenance.
- The Orli Table Lamp is designed for indoor use only. Keep it dry and away from liquids.
- Do not touch the bulb while it is on or immediately after switching off. Allow to cool before handling.
- Never expose the lamp to extreme heat or direct sunlight.
- Do not cover the lamp while in use or charging to prevent overheating.
- The built-in lithium battery is non-replaceable. Do not attempt to modify, repair, or replace the internal battery.
- This lamp contains a built-in lithium battery and electronic components that must not be disposed of with household waste. Take the complete lamp to an authorised recycling or collection centre.

Product Overview & Control Panel

Component	Function
Wood Base & Pole	Provides stability and natural aesthetic
Tapered Shade	Diffuses warm ambient light
Pull-Cord Switch	Turns lamp on/off
USB Charging Port	Located on base or pole for recharging
LED Indicator	Red/orange = charging, green = fully charged

Instructions for Use

1. Unpack Carefully – Remove all packaging and check that all components are included and undamaged.
2. Assemble – Place shade securely on the pole, wider end downward.
3. Charge Before First Use – Connect the USB cable and charge for 4 hours; indicator light will show status.
4. Position Lamp – Place on a stable, flat surface away from edges and flammable materials.
5. Operate the Lamp – Use the pull-cord switch to turn the lamp on & circle through the lighting modes from cool to warm (Fig.1).
6. Battery Life – Full charge provides 6-7 hours of illumination.
7. Charging Indicator – Red light shows charging; green light shows fully charged.

(Fig.1).



Cleaning & Daily Maintenance

1. Wipe the lamp regularly with a soft, dry cloth.
2. For stubborn marks, use a slightly damp cloth and dry immediately.
3. Do not use harsh cleaners, alcohol, or abrasive agents.
4. Keep the USB port and charging cable clean and dry.
5. Charge the lamp at least once every three months, even when not in use

Troubleshooting

Problem	Possible Cause	Suggested Solution
Lamp does not turn on	• Battery not charged • Lamp needs resetting	• Charge for 4 hours • Turn off, wait 10 sec, turn on
Light flickers	Low battery	Charge lamp
Lamp not charging	Faulty cable or port	Try different cable or clean port
Dim light	Battery low	Charge fully
Wood discolouration	Natural aging/patina	Normal, avoid sunlight
Lamp wobbles	Uneven surface	Move to flat, stable surface

Technical Specifications

Supplier Code:	LW768
Product Name:	Orli Table Lamp
Power:	1.3W
Colour Temp:	3000-4000-6000k
Battery:	18650 3.7V 1200 mAh Li-Ion
Charging Time:	4 hrs approx.
Charger:	USB
Size:	32.5 x 15 x 13cm



Technical Support

If you require any technical support for your product within the warranty period, please contact us on: **support@leisurewize.com** and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.

WEEE

The WEEE symbol on this product means that this unit should be ethically dismantled or recycled to minimise environmental impact. Please check with your local authority for more information.

IMPORTANT: ADDITIONAL SAFETY INFORMATION

Warning: This product is not intended for use by children or individuals with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult. Small parts may present a choking hazard. Always keep out of reach of children.

IP44

Leisurewize, a brand of the Ace Supply Company Ltd. (Streetwize)
Suite GA, Marsland House
Marsland Road, Sale M33 3AQ

For Product Support:
support@leisurewize.com

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI