



Foldable Rocking Chair

Use Safely

- Unfold the chair carefully & ensure all the joints are securely locked in place.
- Keep fingers and hands clear of folding mechanisms to avoid pinching injuries.
- Ensure fabric and frame are not twisted before unfolding.
- Use only on stable, level ground. Do not use on uneven, sloped, or slippery surfaces.
- Maximum weight capacity: 120 kg (265 lbs). Do not exceed this limit.
- This chair is designed for one person only.
- Do not modify or alter the chair in any way.
- Do not place near open flames, campfires, heaters, or other heat sources.
- Do not use during strong winds where tipping may occur.
- Avoid prolonged exposure to rain to prevent frame corrosion.

Rocking Safety

- Rock gently and in a controlled manner.
- Do not stand on the chair or use it as a step stool.
- Do not lean excessively backward or forward while rocking.
- Children should use the chair only under adult supervision.

Storage

- Keep the chair clean & dry by wiping with a cloth.
- Always fold the chair completely before transport.
- Store in a dry place to prevent material degradation.



Streetwize,
Suite GA, Marsland House,
Marsland Road, Sale. M33 3AQ

For Product Support:
support@streetwize.co.uk

EU Regd. Address:
Ace Supply Co (Europe) Ltd.,
Dublin 2, D02 A098, ROI