



# Camping Rocking Chair

LW672  
Information For Use



## Contents

Intention for Use	1
Product Elements	2
Assembly Instructions	2
Attaching the Rocking Base	8
Cleaning & Maintenance	8
Health & Safety Guidelines	8
Technical Support	8
Technical Specifications	8

## Intention For Use

Thank you for purchasing the Leisurewize Camping Rocking Chair. This product is intended for both caravan and camping holiday makers, and it is also ideal for use at home for when relaxing in your back garden.

This camping rocking chair can be converted to a sunset chair by simply removing the rocking base attachments.

## Product Elements

1. Slimline carry bag.
2. Aluminium chair frame (unassembled).
3. Rocking base attachments (x 2).
4. Seat fabric.



## Assembly Instructions

Please note, the instructions below outline the steps to assemble this product to use as a sunset chair. The section after these instructions show you how to attach the rocking base attachments.

1. Take out all the components from the carry bag, and lay them on the floor.
2. The chair frame is made of collapsible chair-poles that have an elasticated shock-cord that runs through the middle. When assembling the chair frame, first assemble the central support pole by attaching both joints to either side (see Fig 1 & 2).



3. Then attach the chair legs to the joint (see Figure 3).

Fig 3



Fig 4.



Shows the chair frame with the legs attached.

4. Then, attach the arm rest bars as shown in Figure 5.

Fig 5



5. Assemble the chair poles for the backrest frame (see Figure 6).


Fig 6



Then attach the backrest frame chair poles to the joint as shown in Figure 7.



6. With the seat fabric, place the seat fabric over the backrest frame via the pockets found on either corner of the fabric (see Figure 8).



Please note, when placing the fabric over the backrest frame, you will need to dislodge and disassemble the backrest frame's chair-poles so that the fabric sits in place on the frame.

Fig 9



7. Then, secure the other end of the fabric onto the armrest frame via the pockets (see Figure 10).  
Figure 11 shows fabric firmly in place.

Fig 10



Fig 11



8. Once done, sit the chair upright. This is ready for use as a sunset chair (see Figure 12).

Fig 12



## Attaching the Rocking Base

To convert the chair into a rocking chair, simply attach both rocking base attachments to the frame legs, with the short part of base attachment at the front.

When attaching the base, first insert the front leg to the inlet on the attachment, and push the rear into the rear inlet as shown in Figure 13.



**Please note, when pushing in the rear leg into the attachment, you will need to apply force.**

To remove the attachments, simply pull them both out.

## Cleaning and Maintenance

To maintain the camping rocking chair, clean with a clean damp cloth on a regular basis. The fabric is water resistant so any spillages or marks should easily wipe off.

## Health & Safety Guidelines

- This rocking chair is not a toy. Ensure children are under supervision when they are using the rocking chair.
- Never cut the cord inside the chair-pole.
- Do not jump on the chair. Risk of injury.

## Technical Support

If you require any technical support for your product, please contact us on:

**support@streetwizeaccessories.com** and provide the product name and supplier code (see Technical Specifications) along with the technical query and proof of purchase.

## Technical Specifications

<b>Product Name</b>	Leisurewize Camping Rocking Chair
<b>Supplier Code</b>	LW672
<b>Frame:</b>	Aluminium chair poles with shock-cord elastic
<b>Fabric</b>	600D Oxford
<b>Maximum support weight</b>	120kg
<b>Assembled dimensions</b>	56cm x 65cm x 89cm

We have over 1000 car & leisure products in our range. To find out more follow us on social media.

