



LW669

Rechargeable Dehumidifier

- Protect your caravan & motorhome from damp and condensation.

PLEASE READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE ANY USE OF THE DEHUMIDIFIERS - AND RETAIN FOR FUTURE REFERENCE.

Each unit contains water glass technology crystals.

Water glass is a very absorbent substance that has an absorption rate much higher than traditional soluble humidity absorbing products. It is odourless and will not re-release moisture back into the air. This new water glass technology is the most efficient way to absorb excess moisture.

The “Recharging” nature of this product is simply to dry out the crystals when they indicate maximum moisture absorption (i.e. Pink).

As the crystals absorb water they change colour from BLUE to PINK.

Simply plug in to begin the drying process, when the crystals are BLUE the unit is “Recharged”.

Please Note: There are NO illuminated LED's on this unit.

OPERATING INSTRUCTIONS

1. Check the moisture levels of the crystals in the window on the unit, if they are “Blue/Black” in colour, **recharging is NOT required.** If the crystals appear Pink follow steps 5 & 6 below.
2. To use the dehumidifiers place the units where you require moisture to be eliminated, please ensure the units are not covered.
3. Periodically check the units (every 2-3 weeks), when the crystals indicate they are wet (i.e. Pink) they will have absorbed their maximum amount of water. The units will now need re-charging to dry-out.
4. Shake the units to separate the crystals.
5. **Ensure each unit is an upright position**, when the unit is being re-charged and out of reach of children. **The power point is on the base so the unit, so it re-charges upside down.** Re-charge the units in a suitable and a well ventilated location. The units will heat up during the drying-out process.
6. Plug the charging cable in to the unit, then plug in to a mains plug socket for between 15-24 hours or until water glass crystals indicate they are dry (i.e. Blue), during charging periodically shake the crystals to ensure even drying, when drying is complete unplug the units and replace the units in the required position as previously.



Voltage: 230V ~ 60/50Hz

Power: 25Watts

Temperature & Humidity: 20° to 40°C, more than 50% humidity.

ENVIRONMENTAL PROTECTION:

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.

Check with your Local Authority or retailer for recycling advice.



For your own convenience, make these simple checks before calling the support/service line below.

1. Ensure the units are filled with moisture (i.e. Pink) before attempting ANY recharging?
2. If unit is displaying Blue crystals, they DO NOT need any re-charging.

If the unit does not heat up.

1. Is the unit plugged into a mains power point?
2. Is the fuse in mains plug OK?

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Streetwize Accessories: Unit 1, Royce Trading Estate,
Ashburton Road West, Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com

Telephone: 0161 447 8597

www.streetwizeaccessories.com



M17 1RY