



SWCWB6



Read and understand these instructions before attempting any operation of this Blaster Brush/Broom and retain for future reference!

This Combination Kit Consists of:

1. Blaster Brush II Head.
2. Blaster Water Broom Head.
3. TELESCOPIC Aluminium Pole.
4. Easy Glide ON/OFF Switch.
5. Universal Hose Connector.




HOW TO USE YOUR BLASTER BRUSH

- Mix car shampoo and warm water in a bucket to generate plenty of foam.
- Connect your Blaster Brush to a garden hose with (standard) hose connector (A). Ensure water flow is OFF (B).
- Twist (C) and adjust the telescopic pole to the desired length and re-tighten to secure.
- Turn on the tap and set the switch on your Blaster Brush to ON (B). Spray away surface dirt, debris and grime.
- Switch OFF (B). Dip the brush in soapy water and wash your car (or other item) one section at a time, working from the top, down. Wash the tyres and rims last.
- After washing each section, immediately switch ON (B) for a blasting rinse to avoid soapy streaks.



TIPS FOR THE PERFECT WASH EVERY TIME

- Do not clean with very hot water as this may damage the bristles.
- Only use a quality high foam car shampoo - and use plenty!
- Avoid cleaning with dishwashing liquid or detergent.
- Before use, it is essential to ensure bristles are FREE from grit to avoid scratches.
- Avoid leakage by ensuring all parts are securely screwed together before turning on.
- Avoid using water pressure that is too high.
- Always give the car a blasting rinse first before brushing.
- After use, rinse bristles thoroughly under running water to remove excess suds.
- Store standing upright to avoid bristle damage. Make sure switch is set to OFF.



Ideal to...





BLASTER WATER BROOM INSTRUCTIONS

DO NOT USE ON FINE PAINTED SURFACES SUCH AS CARS, CAMPERS, TRAILERS.

1. Ensure ON/OFF (B) switch and water tap is OFF
2. Attach the Blaster Water Broom Head by unscrewing The Blaster Brush Head (D) (if attached) and reattaching the Blaster Water Broom Head and retighten (D) by hand securely.
3. Connect the pole to a garden hose with hose connector (A) (if not already connected).
4. If no universal hose connector is required (USA), unscrew universal male connector and connect hose directly to pole.
5. Loosen middle pole fastener slightly (C), and adjust the telescopic pole to the desired length, then retighten securely by hand.
6. Ensure water switch on pole and water tap is OFF
7. Connect the pole to a garden hose with the universal hose connector.
8. If no universal hose connector is required (USA), unscrew universal male connector and connect hose directly to pole.
9. Loosen middle pole fastener slightly, and adjust the telescopic pole to the desired length, then retighten securely by hand.
10. Avoid leakage by ensuring all parts are securely screwed together before turning on the tap.
11. Turn ON the tap.
12. Switch the water switch to ON (B) and proceed to wet surface.
13. Depending on application, either leave water switch ON (B) while scrubbing and sweeping surface, or wet surface, switch water switch OFF (B), scrub, switch ON (B) and direct loose dirt to drainage.
14. At times, while water switch is ON (B), lift Blaster Water Broom and use water pressure to thoroughly direct dirt and debris away, as well as rinsing hard to reach areas.
15. Spray away mud, garden refuse and dirt from surfaces to ensure thorough cleaning.

Ideal for...



Streetwize Accessories:

Unit 1, Royce Trading Estate, Ashburton Road West,
Trafford Park, Manchester M17 1RY

Sales enquiries: sales@streetwizeaccessories.com

Technical enquiries: support@streetwizeaccessories.com
www.streetwizeaccessories.com