

# SWCV Car Vacuum Cleaner 12V

## Operation Instructions:

**Caution!** Do not use this appliance on inflammable or sharp edged objects, hard dirt or similar objects! This is dangerous and the unit is not suited for such purposes.

Use this appliance for domestic purpose or in the car only. Do not use it on animals or people to avoid injury. Never use the appliance without the filter or with a damaged filter. This can cause damage to the motor and injury by loose debris.

- 1 To operate the appliance insert 12V plug into 12V power (cigarette lighter) socket and switch the vacuum cleaner on.
- 2 The crevice tool can be attached into the suction opening, for difficult to reach places.
- 3 Hold the suction opening directly to the dust. When sucking liquid or water please only collect small amounts of liquid. Collecting large amounts of liquid could cause damage.
- 4 After finishing, switch off and empty the dust container. Please do not overfill the dust container and empty the dust container after each use. If it is overfilled, dirt could fall out of the suction opening while using the unit.
- 5 Never place the unit near any sources of heat.
- 6 Ensure that the suction opening is not blocked by debris, hair etc. To avoid reduced suction power or overheating of the unit.

## Important Safeguards:

Please read this instruction manual carefully before use and keep in a safe place for future reference. If you give the appliance to another person, also supply them with the instruction manual.

Intended use: This appliance is suited for manual vacuum cleaning (in smaller areas). Only use the appliance for domestic purpose - the appliance is not suited for commercial use. Only use the appliance in the way indicated in this instruction manual. To avoid damage or danger by improper use this user instruction manual should be followed carefully.

Caution! Do not operate any appliance if:

- Power cable is damaged, in case of malfunction or if it has been dropped or damaged in any way.
- Should the cable be damaged, it must be replaced by a competent qualified electrician (\*) to avoid any danger caused by electric current.

(\*) Competent qualified electrician: any person who is qualified, approved and competent to perform this kind of repair in order to avoid all danger.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Never leave the appliance unsupervised when in use. Children are not aware of the

danger that can be caused by using electric appliances. Explain to your children all risks which can be caused by electric current.

- Danger caused by hot parts of the appliance and exhausting hot air.
  - Danger caused by electric current (electric shock, short circuit, fire danger).
- 
- Keep the appliance at all times out of reach of children or persons who can not handle electric appliances properly.
  - Do not leave packaging components (plastic bags, cardboard, polystyrene, etc.) within the reach of children, as it could be dangerous - danger of suffocation!

**Caution! Risk of electric shock!**

Appliance, cable and plug should never get into contact with water or any other liquids:

- never immerse the appliance, the cable or the plug in water or any other liquid for any reason whatsoever
  - the cable should never get wet or come into contact with moisture or humid objects.
  - never touch the appliance with wet hands or standing on wet ground
  - never place the appliance on wet ground
  - never use the appliance outdoors
- Never move the appliance by pulling the cable. Make sure the cable cannot get caught in any way. This helps avoid accidents.
  - Do not wind the cable around the appliance and do not bend it.
  - Ensure that the cable does not touch sharp edges and hot objects nearby.
- From time to time check if the cable is damaged. In this case or if the appliance is damaged it must not be used any more.



**Streetwize Accessories**

E-mail: [sales@streetwizeaccessories.com](mailto:sales@streetwizeaccessories.com)

[www.streetwizeaccessories.com](http://www.streetwizeaccessories.com)