

Dual Rechargeable Light Stream

ULTRA BRIGHT LED LIGHT STREAM WITH BUILT-IN HOOKS AND MAGNETS FOR SUSPENSION



SWLR31 Dual Rechargeable Light Stream Owner's Manual & Warranty Information

READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT. RETAIN THIS OWNER'S MANUAL FOR FUTURE REFERENCE.

SAFETY WARNINGS

- Do not allow children to operate this Rechargeable LED Work Light.
- Do not use this for other purposes than its intended use.
- Do not use when the charger is plugged in.
- Never operate if any part of it is corroded or damaged.
- Never submerge in water.
- Never charge the Rechargeable LED Work Light around water (including rain), fire or explosive hazards
- Never operate near flammable materials or any location where flammable fumes may accumulate.
- Never allow the Work Light to be exposed to fire, direct flame or high-heat sources.
- Always turn off when not in use.
- Do not disassemble or remove any parts. This Rechargeable LED Work Light contains no user serviceable or replaceable parts.
- Clean the Work Light and charging accessories regularly.

FEATURES

- Contact Pins 7. Charging Port
- 120 LEDs
- Red LED Charging Indicator
- ON/OFF Switch
- Fold-Out Hooks
- Magnets
- Coupler
- 12-Volt DC Charging Adapter

- 230-Volt AC Charging Adapter
 700 Lumens
 Dun time, per charge (120 LEE)
- Run time per charge (120 LED bulbs) 2.0 hours
- Battery 74-volt Li-Ion, 13.32 Watt-Hours
- Charge time AC charger 5 hours; DC charger 5 hours
- AC charger Input 230-volt; output 12-volt 300 mA
- DC charger Input 12-volt; output 12-volt with 2A fuse
- LEDs 120 white LEDs and 1 charging LED

• 2-amp Fuse

CHARGING

This Rechargeable LED Work Light is shipped in a partially charged state. BEFORE first use, charge the battery using the 230-volt AC charging adapter for 5 hours. Failure to follow this procedure may permanently damage the battery.

CHARGER FEATURES

The 230-volt AC charging adapter allows charging from a household wall outlet (230 volts AC) and connects to the charging port at the bottom of the handle.

The 12-volt DC charging adapter allows charging from a 12-volt DC power socket and connects to the charging port at the bottom of the handle. A red LED charging indicator is next to the 120 LED lights, and whilst charging the red LED charging indicator will be illuminated. When fully charged the indicator will turn green.

CHARGING GUIDELINES AND PRECAUTIONS

- Only use the charging adapters that were provided with this Rechargeable LED Work Light. Use of other chargers or adapters may void any warranty, cause product damage, increase risk of fire, and/or result in personal injury.
- Keep the charging adapters dry and free of dirt/dust at all times. Do not submerge them in water or any liquid.
- Do not overheat or overcharge the battery.
- NEVER turn on while charging as this may damage the Work Light and may void any warranty.
- •Once the battery is discharged, recharging will take 5 hours with the 230-volt AC charging adapter to reach full charge.
- Do not charge the battery for more than 24 hours.
- Ensure the power switch is set to the OFF position.
- Connect the AC charging adapter to the Work Light charging port and then plug into an approved outlet. The indicator will illuminate whilst charging: Ensure adapter connections are secure.
- When the Light is fully charged, the red LED charging indicator will turn green.

12-VOLT DC CHARGING

Be sure the 12-volt DC power socket and 12-volt DC charging adapter power plug are clean before connecting the 12-volt DC charging adapter. Corro-



sion and poor electrical contact may cause damage and poor performance or even fire.

Never turn the Rechargeable LED Work Light on while charging, as this may cause damage and void any warranty. Keep the ON/ OFF switch to the OFF position at all times during charging.

Disconnect the 12-Volt DC charging adapter from the power socket before cleaning the adapter. Be sure to allow the adapter to cool before cleaning. Once the battery is discharged, recharging will take 5 hours using the 12-volt DC charging adapter to reach full charge. Do not charge the battery for more than 24 hours using the 12-volt DC charging adapter.

- Switch the ON/OFF switch to the OFF position.
- Connect the 12-Volt DC charging adapter to the charging port and then plug the 12-Volt DC charging adapter into a 12-Volt DC power socket and twist it to ensure a good connection.
- The red LED charging indicator will illuminate indicating it is charging. If the red indicator does not illuminate while charging: Ensure the 12-volt DC charging adapter connections are secure.
- Check the 2-amp fuse in the end of the 12-volt DC charging adapter.
- When the LED Work Light is fully charged, the red LED charging indicator will turn to green.

CHARGING TIPS

- Recharge as soon as possible once the Work Light starts to dim and after each use.
- Once charging is complete, disconnect the charger cord and wait 5 minutes before use.
- Never leave the battery discharged or completely discharge battery as this will decrease battery life.
- Recharge every 2 months during periods of non-use.
- Disconnect the power from the charger adaptor when not in use.

OPERATING INSTRUCTIONS

Do not operate the Work Light when the 12-volt DC charging adapter or the 230-Volt AC charging adapter is connected. Ensure the battery is completely charged before operating.

Please note only one side of this product will work independently, it is NOT possible to use both sides independently.

- Push either ON/OFF switch to turn the 60 LED lights.
- Push the ON/OFF switch again to turn on all 120 LED lights.
- Pushing the ON/OFF switch a third time turns off all the LED lights.
- NOTE: When the lights are disconnected, only the light with the charge port will operate.
- To disconnect the lights, turn the coupler counterclockwise and using a constant pulling motion separate the two halves.
- To operate the single 60 LED light, press the ON/OFF button to turn on the lights.
- Press the ON/OFF button again to turn off.
- To reconnect the lights, line up the grooves and slide the lights together so the contact pins touch.
- Turn the coupler clockwise to thread it onto the other light.

USING THE FOLD-OUT HOOK(S):

- Pull the fold-out hook out from its stored position to allow the Rechargeable LED Work Light to be hung from a suitable fixture.
- Keep the fold-out hook snapped into its storage position when not in use.

USING THE HANDS-FREE MAGNETS:

- The magnets can be used to hold the Work Light in a desired position for hands-free operation.
- Place the magnets on a suitable metal (steel) surface to hold the Work Light in position.

CARE & MAINTENANCE

Due to inherent self-discharge, batteries should be charged at least every 2 months, especially in warm environments. Leaving a battery in a discharged state, or if not recharged every 2 months, may result in permanent battery damage.

- Charge the Rechargeable LED Work Light every 2 months during periods of non-use.
- Unplug the Rechargeable LED Work Light and charging adapter and allow to cool before attempting to clean.
- To clean, use a soft cloth moistened with a mild solution of water and detergent on the outer surface of the Rechargeable LED Work Light.

FUSE REPLACEMENT

- Disconnect the 12-Volt DC charging adapter from the 12-volt DC power supply and Rechargeable LED Work Light.
- Turn fuse holder cap counterclockwise to remove cap and fuse.
- Clean fuse socket and terminals as required.
- Replace fuse with equivalent 2-amp fuse.
- Install cap and tighten clockwise by hand.

BATTERY REPLACEMENT / DISPOSAL

The Work Light is designed to provide years of service. However, when the internal battery reaches the end of its service life, the Rechargeable LED Work Light itself is no longer of use. The internal battery is not designed to be user replaceable. This Work Light should be recycled or safely disposed of at a local recycling center.



Streetwize: Ashburton Road West, Trafford Park, Manchester M17 1RY www.streetwizeaccessories.com

For product support: E: support@streetwizeaccessories.com T: +44 (0)161 447 8597 For trade enquiries: E: sales@streetwizeaccessories.com T: +44 (0)161 447 8580 For spare parts: E: spareparts@streetwizeaccessories.com